

How to Use Super Jiggler

Before using, drain all liquid from hose.

End of tube must be lower than pump before siphoning will start.

Submerge pump into liquid that is to be siphoned.

Move pump vigorously in an up and down motion. It is important that the pump remain in liquid at all times to start the siphoning. Once the flow starts, stop moving or shaking the pump as gravity will maintain the flow of the liquid.

Once siphoning starts, keep the pump submerged in liquid.

To stop siphoning, remove the pump from liquid.

Drain all liquid from hose and clean thoroughly.

Store in a cool dry place.

